

# MEI Bank Note Recycler (BNR)

How to load bills into the BNR for the first time



# Loading bills into the BNR for the first time

- 1) Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.
- 2) Place (25) \$1 bills into the loader cassette.
- 3) Return the loader cassette to the BNR.
  - a) Press the Interlock release down, turn the Interlock latch to the left.
  - b) Let the recycler auto fill.
- 4) Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.
- 5) Place (57) \$5 bills into the loader cassette
- 6) Return the loader cassette to the BNR.
  - a) Press the Interlock release down, turn the Interlock latch to the left.
  - b) Let the recycler auto fill.
- 7) Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.
- 8) Place up to (250) \$1 bills into the loader cassette. The loader indicator must be green.
- 9) Return the loader cassette to the BNR.
  - a) Press the Interlock release down, turn the Interlock latch to the left.
  - b) Let the recycler auto fill, if any.
  - c) The unit is now ready for production sales.

Interlock release



Interlock latch



Step 1:

Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.



Loader cassette



Step 2:  
Place (25) \$1 bills into  
the loader cassette



### Step 3:

Return the loader cassette to the BNR

- a) Press the Interlock release down, turn the Interlock latch to the left.
- b) Let the recycler auto fill

Interlock release



Interlock latch



Loader cassette

Interlock release



Interlock latch



Step 4:

Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.



Loader cassette

Step 5:  
Place (57) \$5 bills into  
the loader cassette



Step 6:

Return the loader cassette to the BNR

- a) Press the Interlock release down, turn the Interlock latch to the left.
- b) Let the recycler auto fill



Loader cassette



Step 7:

Turn the Interlock latch to the right, press the Interlock release up, remove the loader cassette.

Interlock release



Interlock latch



Loader cassette



## Step 8:

Place up to (250) \$1 bills into the loader cassette.

The loader indicator must be green.

Loader Indicator

NOTE: The loader indicator shows if the loader can accept the quantity of bills placed in the loader. If the indicator is green, the quantity is good. The loader can hold up to 250 bank quality bills. The worse the quality of the bills, the less quantity that can be held.



Step 9:

Return the loader cassette to the BNR

- a) Press the Interlock release down, turn the Interlock latch to the left.
- b) Let the recycler auto fill, if any.
- c) The unit is now ready for production sales.



Interlock release



Interlock latch



Loader cassette



# MEI Bank Note Recycler (BNR)

How to load bills into the BNR for the first time

