LPR Focus & Zoom

Initial set-up or adjusting

To access the camera, you must be on the Dencar network, or VPN connected to the site. If at the site, connect to the physical Dencar network ports via wired connections or connect to the Dencar WIFI network. The WIFI credentials are included in the Introductory Information packet sent to the owner.

The camera uses a program to access it that requires an Internet Explorer experience to view the video stream. We typically use the Chrome browser, so you need to add “IE Tab” to the Chrome browser.

Download IE Tab from the Chrome Web Store. Search “Chrome IE Tab” or follow this link: https://chrome.google.com/webstore/detail/ie-tab/hehijbfgiekmjfkfjpbkbammjbdenadd?hl=en-US

The camera is connected to the network per the assigned IP address. Open your browser and input the IP address in the URL field, press enter, and the login popup will appear.



Note: The camera IP address of your camera will be unique. Look at your network details sheet for your IP addresses.

The default camera username and password is admin / admin. This can be changed after login. Don't change this until instructed to do so.

Once you reach this page, select the IE Tab icon. This is what you installed previously from the Chrome web store. When you select this icon, the page will reload and prompt another login to the camera. This is shown on the next page.





The default camera username and password is admin / admin. This can be changed after login. Don't change this until instructed to do so.

Setup the software if this is the first time accessing a camera from your computer.

After that, go to “PC View”



You now have a live view of the camera. Manually adjust zoom and focus on the camera (shown on the next page) while watching this video stream.



Inside the camera, these are the focus and zoom controls. Loosen to adjust, tighten once set.

Adjusting the name and time stamp on the LPR camera is shown on the next pages.

To adjust the name shown on the LPR camera:

1) Go to Settings
2) Select OSD set
3) Enter the name
4) Select Apply



To adjust the time/date stamp shown on the LPR camera:

1) Go to Settings
2) Go to System
3) Select Time
4) Update as appropriate
5) Select Apply



Conclusion:
LPR Focus & Zoom

Initial set-up or adjusting